KitchenAid®

OVEN PARTS

For Model: KEBS177DSS7

(Stainless Steel)

27" BUILT-IN ELECTRIC
SINGLE OVEN
THERMAL CONVECTION



NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Trim, Side
	4452079	Right Hand
	4452080	Left Hand
	4449041	Screw
4	4448520	Bumper, Door
5	4452490	Spacer, Foam
7	4452236	Top Chassis
	4449809	Screw
8	4452489	Deflector, Vent Box
9	4452158	Tube, Vent
	4449154	Screw
10	4452163	Lens, Light
11	4448972	Oven Light Assy
	4449748	Screw
12	4452164	Bulb, Light
13	4452336	Insulation, Bottom Vent
14	4451739	Frame, Front
	4449040	Screw
	4450118	Nut
15	4449371	Gasket, Door
16	4452152	Bracket, Mounting
	4450289	Screw
19	4451477	Support, Insulation
	4449809	Screw
20	4451605	Cap, Spacer
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451896	Latch Assy
23	4452224	Solenoid
24	4451422	Micro Switch N.C.
	4449154	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452233	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Micro Switch
29	4451665	Sensor
	4449154	Screw
30	4451537	Spring, Latch
33	4450280	Deflector, Vent
37	4452223	Thermostat (TOD)
	4449809	Screw
43	4451397	Base, Chassis
	4449809	Screw
49	4448933	Retainer
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
51	4452480	Trim, Bottom Vent
	4450289	Screw

53	4449845	Support, Bracket

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449315	Insulation, Wrap
4450364	Insulation, Back

CONTROL PANEL PARTS

For Model: KEBS177DSS7

(Stainless Steel)



NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451790	Control Panel Assy.
2	4452362	Switch, Membrane
3	4452248	Insulator, Board
4	4452249	Insulator, Board Support
	4159465	Screw
5	4452260	Spacer, Foam
6	4452345	Insulator, Dialectric
7	4451845	Microcomputer
	3400406	Screw

LITERATURE PARTS

LIT4450410	Installation Instructions
LIT3192225	Installation, Undercounter
LIT4450841	Installation, MWO Trim Kit
LIT4450571	Use & Care Guide
LIT4449066	Cookbook T/C
LIT4451876	Tech Sheet
LIT4449264	Guide, Easy-Set
LIT3191638	Safer Cooking Tips

OVEN DOOR PARTS

For Model: KEBS177DSS7

(Stainless Steel)



NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451718	Door Liner
2	4454948	Hinge, Door
	4449743	Screw
3	4451721	Insulation, Door
4	4449253	Glass, Inner
5	4451670	Retainer, Glass
	4449809	Screw
6	4450361	Shield, Heat
	4449809	Screw
7	4449257	Glass, Inner (2) for BS Model
9		Bracket, Handle
	4452487	Right Hand
	4452488	Left Hand
	3196184	Screw
10	4452325	Seal, Top
11	4452087	Handle
13	4452315	Assy, Door Glass
16	4451668	Retainer, Glass (2) for BS Model
	4449809	Screw
18	4451432	Clip, Retainer

INTERNAL OVEN PARTS

For Model: KEBS177DSS7

(Stainless Steel)



2	4452156	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3181534	Rack, Roasting
6	4448715	Rack, Oven
7	4452155	Element, Bake
8	4448881	Nut, Hex
9	4451583	Fan, Convect. Assy
	4449154	Screw
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4448722	Tray, Bake
17	4450039	Cover, Bake Tray
	4449809	Screw
20	4452157	Element, Convection
	4449154	Screw
21	4448418	Cover, Fan
	4449154	Screw

TOP VENTING PARTS

For Model: KEBS177DSS7

(Stainless Steel)



1	4451759	Vent, Exhaust
	4449040	Screw
2	4451438	Elbow, Vent-top
3	6610168	Blower
4	4451752	Elbow, Vent-bottom
5	6610122	Transformer, Light
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
16	4450550	Cover, Top Rear
	4449809	Screw
17	4448664	Clamp
	4449809	Screw
18	4452366	Cover, Top Front
	4449809	Screw
21	4451758	Seal, Foam
7	4451789	Plate, Mounting
10	4451891	Transformer, Control
11	4449868	Block, Terminal
	3196181	Screw
13	4448548	Vent, (Control Panel)
	4159465	Screw
14		Side, Control Top
	4451597	Right
	4451598	Left
	4449809	Screw

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

ADHESIVE

591014	Adhesive Loctite (1/3 oz.)
482338	Sealer, Silastic (3 oz.)

SPLICING WIRES--25FT. LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

WIRING HARNESS PARTS

4454842	Tie, Cable
4449809	Screw
4450952	Conduit
4450800	Screw, Ground
4448664	Clamp
4449809	Screw
112432	Nut
4451761	Support, Wiring
4451861	Harness, Wire (Main)
4452222	Spacer, Harness
4454835	Tie, Cable

Miscellaneous

814381	Hinge Pin Kit
4448950	Screw, Install (4)